A2



ANDERSEN

ANDERSEN DISCLAIMER

The Andersen A2 should only be installed by an electrician with the appropriate knowledge and qualifications to carry out this type of electrical installation. Failure to do so could result in injury or death.

It is the responsibility of the installer and/or designer to determine the correct residual and overcurrent protection where external influences could have an effect on inbuilt protection.

Opening of containment should only be carried out when the supply is isolated from the mains. The undertaking any live testing should only be carried out by a person or persons qualified to do so.

The installation instructions should be followed closely to ensure correct installation and commissioning. Failure to follow these instructions could result in damage to the Andersen charger, existing installation or supplier's equipment.

During and on completion of the installation, the installation shall be inspected and tested to verify that it complies with the latest amendment of the BS7671.

Before the Andersen A2 is put into service, we as the manufacturer require the installer to simulate a charge with a recognised EVSE adaptor and multifunction tester.

Use of this equipment should only be undertaken by someone who has an understanding of its functions and has the experience and knowledge to do so.

www.andersen-ev.com

A2-012020V2

ANDERSEN A2



sunk screw

washer

OPERATION LED STATUS

LED flash together twice a second

- Standby State (solid green)
- Vehicle connected state (solid green & solid amber)
- **Vehicle charging state (solid amber)**
 - Charge point locked or awaiting scheduled charge (solid green & solid red)

ERROR & UPDATE LED STATUS

Disconnected from network/cloud (green LED flash every 5 seconds)



RCM or charge error (blip red every second)

Firmware upgrade (sequence of green, amber, red for duration of upgrade)

SETUP LED STATUS

Wifi Setup (Amber LED flash once per second)

Reset warning. Red, Amber, Green LED flash

Multi function button located at the bottom left inside the cable slot



SETUP MULTI FUNCTION OPERATION

x2 Reset RCM (Two button presses)





Enter unit reset mode (Five button presses) + Exit Timeout 30 secs



x2 6mm washer









Fuse CT sensor cable * Optional

0



determined during testing.

Recommended Cable: Shielded twisted pair e.g. CAT5e/CAT6

Solar Basic/Adaptive CT

Note: Fit CT clamp to incoming supply. Orientation can be determined during testing. CT orientation can be confirmed in dashboard using a load reference i.e. kettle 3Kw

Recommended Cable: Shielded twisted pair e.g. CAT5e/CAT6



www.andersen-ev.com/support





+44 (0) 203 8904510

Andersen Chat















\land Danger

Danger to life due to electrical voltage! Injuries due to electric shock and/or burns, possibly resulting in death, are possible. During all work, make sure at all times that power to the system is switched off and secured so it cannot inadvertently be switched on.

- Before commissioning the device check that all screw and terminal connections are tight.
- The termination panel covers must never be left opened without supervision. Fit the termination panel cover when you leave the charge point.
- Do not make any unauthorised changes or modifications to the charge point.
- Repair work to the charge point may only be completed by the manufacturer or a trained expert.
- Do not remove any identifiers such as safety symbols, warning instructions, rating plates, labels or cable markings.
- Ensure that the charging cable is not mechanically damaged (kinked, jammed or run over) and that the contact area does not come into contact with heat sources, dirt or water.

🕂 Warning

Safety notice:

- Isolate all poles and from all live sources.
- Lock off to prevent re-energising of the supply.
- Verify isolation from the supply.
- Electrical saftey warning notices applied.
- Cover neighbouring live parts and cordon off danger areas.

A Caution

Ensure that the charge point is not damaged by incorrect handling (housing cover, internal parts, etc.).

On outdoor installations, do not open the termination panel cover in damp conditions.

Danger of breaking the plastic housing.

- · Do not tighten the securing screws with force.
- The installation surface must be completely flat, do not bend the housing.
- Electronic components may be damaged if handled. Before handling modules, perform an electrical discharge process by touching a metallic earthed object.

A failure to follow the safety information may result in a danger of death, injury and damage to the device. The device manufacturer cannot accept any liability for claims resulting from this.